

Please read and save this Repair Parts Manual. Read this manual and the General Operating Instructions carefully before attempting to assemble, install, operate or maintain the product described. Protect yourself and others by observing all safety information. The Safety Instructions are contained in the General Operating Instructions. Failure to comply with the safety instructions accompanying this product could result in personal injury and/or property damage! Retain instructions for future reference.

Centrifugal Laundry Tray Pump

Refer to form 1808-634-00 for General Operating and Safety Instructions.

Description

This centrifugal laundry tray pump is designed for gravity-feed pumping operations. Unit can handle laundry water or other nonflammable, non abrasive fluids compatible with pump construction. Pump is equipped with mechanical seal (carbon face with Buna-N seal cartridge), cast aluminum body and impeller, and a split-phase motor. This is a manual unit, no controls are supplied.

Unit does not come supplied with any type of switch or control device to turn unit on or off.

For additional pump information, see Specifications and Performance.




Figure 1 - Dimensions (±1/8")

Specifications

- Suction Inlet 1/4" NPT
- Discharge Outlet 1/4" NPT
- Motor 1/4 HP
- Power Supply 115V, 60 Hz
- RPM 1725
- Weight 18 Lbs.
- Max Liquid Temp 120°F

NOTE: Driver data is subject to change without notice, see label on driver for actual specifications.

Performance

GPH of Water at Total Head in Feet						
2'	4'	6'	8'	10'	11'	
1400	1200	1000	700	250	Shutoff	

Installation

Refer to Figure 2 and proceed as follows:

1. Locate pump as close to the laundry tub as possible. Support the pump and piping adequately to keep pump and piping from being strained.
2. Pitch the piping from tub drain to pump suction to avoid air traps. (Do not use the conventional trap). Keep the pipe-size at least 1/4". Use pipe dope to avoid joint leakage. Install necessary piping for pressure switches or any other control devices (not supplied). Follow manufacturer's instructions for their installation.
3. Install a check valve on the discharge side to prevent drain-back.
4. Locate check valve below level of bottom of tub.
5. Wire motor by following wiring diagram on nameplate. It is strongly recommended that this unit is plugged into a GFCI (Ground Fault Circuit Interrupter). Consult your local electrician for installation and availability. Be sure unit is grounded (General Safety Information). If unit is to be controlled by an on and off switch, install at this time.




Figure 2 - Typical Installation

Centrifugal Laundry Tray Pump

Installation (Continued)

6. If laundry water from a washer is discharged into the laundry tub, it should be filtered. Filtering can be accomplished many ways. An easy way is by taking an old pair of panty hose, putting one leg into the other, and then putting it on the end of the washer discharge hose with a rubber band. Most of the panty hose should be lying in the laundry tub. Eventually, the panty hose will become full of lint and a hole will develop. The panty hose should then be replaced.

7. Installation is now complete.

NOTE: To prevent accidents, locate motor in a suitable (ventilated) enclosure, or guard all moving parts and ventilation openings.

Operation

Turn unit on by either plugging pump in, turning switch on, or if unit is installed with an automatic device, (not supplied) it will activate itself as well as turn itself off. On units without automatic devices, it is necessary to shut pump off when water stops draining out of the tub (last couple of inches). The pump has become airborne. After a few seconds, when the water has gone down, turn unit on again. The unit may have to be turned on and off a few times to completely drain tub. This is normal. When water has been completely pumped out of the tub, turn pump off immediately.

Maintenance

⚠ WARNING *Disconnect from power source before servicing or inspecting the pump for any reason. Failure to do so could result in fatal electrical shock!*

MOTOR

Dirt accumulations can cause motor overheating and a fire hazard. Remove dirt accumulations from the motor, especially in and around vent openings by vacuuming.

Periodically inspect the installation.

Check for dirt accumulations; unusual noises or vibration; overheating; worn or loose couplings, sheaves and belts; high motor current; poor wiring or overheating connections; loose mounting bolts or guards.

The motor used with this pump uses sleeve bearings which require periodic re-oiling. Each motor has two bearings, which should be lubricated once a year. The bearings are located around the motor shaft (See Figure 3), at each end of the motor. The oil reservoirs have plastic plugs covering them. Pull out the plugs and put oil in. Replace plugs after oiling.

Follow re-oiling instructions on the motor (see nameplate or terminal box cover). If instructions are not included, re-oil once a year with 30-35 drops of SAE No. 20 non-detergent or electric motor oil. Do not over-lubricate.




Figure 3 – Location of Sleeve Bearings for Lubrication

PUMP

There is no normal pump maintenance. Some work might be required on the pump when output has been reduced or when seal leaks. This can be caused by lint build-up around the impeller. Disassemble pump (See Mechanical Seal Replacement), remove impeller (Ref. No. 5) and clean out, then re-assemble.

MECHANICAL SEAL REPLACEMENT

After pump has been in service for a long period of time, or if pump has been in severe service, it may be necessary to replace shaft seal assembly (Ref. No. 3 & 4). Leakage can be detected by a dripping or flow of liquid from area around motor shaft (Ref. No. 1).

⚠ CAUTION *The precision lapped faces on shaft seal assembly are easily damaged. Handle your replacement seal carefully and read these instructions before attempting to replace seal.*

Refer to Figure 6 for Parts Illustration.

1. Disassemble casing (Ref. No. 8) and casing seal (Ref. No. 7) from adapter (Ref. No. 2) by removing fasteners (Ref.No. 9).
2. Notice the location of impeller (Ref. No. 5) on shaft. It should be compressing seal cartridge (Ref. No. 3). Loosen fastener (Ref. No. 6) and impeller will slide off shaft.
3. Pry seal seat (Ref. No. 4) from impeller recess with a small




Figure 4 – Mechanical Seal

screwdriver (see Figure 4).

4. Press old seal cartridge out of adapter by pushing from motor side.

NOTE: Use a 1 1/4" pipe or a socket from a tool set.

5. Clean adapter seal cavity before inserting new seal cartridge.
6. Carefully wipe polished surface of new seal seat with a clean cloth.
7. Wet the rubber portion of seal seat

For Repair Parts, contact dealer where pump was purchased.

Please provide following information:

- Model number
- Serial number (if any)
- Part description and number as shown in parts list




Figure 6 – Repair Parts Illustration

Repair Parts List

Ref. No.	Description	Part Number	Quantity
1	Motor	1626-048-00	1
2	Adapter	1586-001-01	1
3&4	† Shaft seal assembly -Buna N	1640-161-93	1
5	Impeller	1585-000-01	1
6	Fastener	*	1
7	Casing seal -Buna N	1531-000-00	1
8	Casing	1584-000-01	1
9	Fastener	*	5

(†) Available as a set only.

(*) Standard hardware item, available locally.